#### NASA/CR-2007-215094



### Development and Processing Improvement of Aerospace Aluminum Alloys—Development of AL-Cu-Mg-Ag Alloy (2139)

Alex Cho Alcan Rolled Products, Ravenswood, West Virginia

W. Barry Lisagor and Thomas T. Bales Analytical Services & Materials, Inc., Hampton, Virginia Since its founding, NASA has been dedicated to the advancement of aeronautics and space science. The NASA Scientific and Technical Information (STI) Program Office plays a key part in helping NASA maintain this important role.

The NASA STI Program Office is operated by Langley Research Center, the lead center for NASA's scientific and technical information. The NASA STI Program Office provides access to the NASA STI Database, the largest collection of aeronautical and space science STI in the world. The Program Office is also NASA's institutional mechanism for disseminating the results of its research and development activities. These results are published by NASA in the NASA STI Report Series, which includes the following report types:

- TECHNICAL PUBLICATION. Reports of completed research or a major significant phase of research that present the results of NASA programs and include extensive data or theoretical analysis. Includes compilations of significant scientific and technical data and information deemed to be of continuing reference value. NASA counterpart of peer-reviewed formal professional papers, but having less stringent limitations on manuscript length and extent of graphic presentations.
- TECHNICAL MEMORANDUM. Scientific and technical findings that are preliminary or of specialized interest, e.g., quick release reports, working papers, and bibliographies that contain minimal annotation. Does not contain extensive analysis.
- CONTRACTOR REPORT. Scientific and technical findings by NASA-sponsored contractors and grantees.

- CONFERENCE PUBLICATION. Collected papers from scientific and technical conferences, symposia, seminars, or other meetings sponsored or co-sponsored by NASA.
- SPECIAL PUBLICATION. Scientific, technical, or historical information from NASA programs, projects, and missions, often concerned with subjects having substantial public interest.
- TECHNICAL TRANSLATION. Englishlanguage translations of foreign scientific and technical material pertinent to NASA's mission.

Specialized services that complement the STI Program Office's diverse offerings include creating custom thesauri, building customized databases, organizing and publishing research results ... even providing videos.

For more information about the NASA STI Program Office, see the following:

- Access the NASA STI Program Home Page at http://www.sti.nasa.gov
- E-mail your question via the Internet to help@sti.nasa.gov
- Fax your question to the NASA STI Help Desk at (301) 621-0134
- Phone the NASA STI Help Desk at (301) 621-0390
- Write to: NASA STI Help Desk NASA Center for AeroSpace Information 7115 Standard Drive Hanover, MD 21076-1320

#### NASA/CR-2007-215094



### Development and Processing Improvement of Aerospace Aluminum Alloys—Development of AL-Cu-Mg-Ag Alloy (2139)

Alex Cho
Alcan Rolled Products, Ravenswood, West Virginia

W. Barry Lisagor and Thomas T. Bales Analytical Services & Materials, Inc., Hampton, Virginia

National Aeronautics and Space Administration

Langley Research Center Hampton, Virginia 23681-2199 Prepared for Langley Research Center under Contract NNL04AB64T

The use of trademarks or names of manufacturers in constitute an official endorsement, either expressed o National Aeronautics and Space Administration.	n this report is for accurate reporting and does not r implied, of such products or manufacturers by the
Available	from:
SA Center for AeroSpace Information (CASI) 5 Standard Drive lover, MD 21076-1320	National Technical Information Service (NTIS) 5285 Port Royal Road Springfield, VA 22161-2171

#### **Final Report Supplement**

#### **Development and Processing Improvement of Aerospace Aluminum Alloys**

Development of Al-Cu-Mg-Ag Alloy (2139)

NASA Contract No. NNL04AB64T/GS-23F-0281K

This final report supplement in presentation format describes a comprehensive multitasked contract study to continue the development of the silver bearing alloy that was initiated under the original contract study before modification. The initial contract activity included two commercial scale ingots rolled in one inch gauge plate, now registered as aluminum alloy 2139 by the Aluminum Association. It did not include characterization of the rolled product in thicker gauges, or correlation of processing, metallurgical structure, and properties of such thicker gauges. This supplement presents the additional work conducted in this endeavor. The study was funded by the Advanced Space Transportation Programs Office and managed initially by the Metals and Thermal Structures Branch and more recently by the Advanced Materials and Processing Branch, Structures and Materials Competency. Mr. John A. Wagner served as the Technical Representative of the Contracting Officer. The primary contractor was Analytical Services and Materials Inc. and the program manager was Mr. W. Barry Lisagor, a senior scientist with AS&M. The major portion of the experimental work completed under this supplement was conducted by ALCAN Rolled Products LLC., as a principal subcontractor and the principal investigator was Dr. Alex Cho, a senior scientist with ALCAN Rolled Products.

Under the task supplement on aluminum alloy 2139, considerable progress has been achieved in raising the technology readiness level of this promising new alloy to near application status.

The additional two commercial scale ingots were processed into nominal plate gauges of two, four and six inches, and were extensively characterized in terms of metallurgical and crystallographic structure, and resulting mechanical properties. Emphasis was focused on durability and damage tolerance as well as strength and resistance to environmental degradation.

Alloy 2139 is processed by conventional stress relieve and artificial aging practices but does not require the cold deformation processing to develop attractive combinations of strength, toughness, and fatigue crack growth resistance as do conventional 2XXX alloys. This is due primarily to the fact that the strengthening phase, omega, is homogeneously precipitated upon aging, compared to theta prime in more conventional alloys which is heterogeneously precipitated and requires cold work to develop initiation sites for the aging process.

This report includes comparisons of the property combinations for this alloy and 2XXX and 7XXX alloys more widely used in high performance applications. It shows the dramatic improvement in all combinations of properties, including ballistic impact

performance which cannot be overlooked in this potentially important application. Moreover, the properties of this alloy are retained in all gauge thicknesses, contrary to typical reductions observed in thicker gauges of the other alloys in the comparison. The advancements achieved in this study are expected to result in rapid, widespread use of this alloy in a broad range of ground based, aircraft, and spacecraft applications.



### **Development of Al-Cu-Mg-Ag Alloy (2139)**

Alex Cho

Alcan Rolled Products
Ravenswood WV

NASA Contract No. NNL04AB64T with AS&M Inc.





#### **Contents**

- I. Background
- II. Metallurgical attributes of the Al-Cu-Mg-Ag alloy system
- III. Development of 2139 (Al-Cu-Mg-Ag alloy) wrought productEffect of dispersoid forming elements
- IV. Development of 2139 thick gauge plate product
- V. Summary & Conclusion





### I. Background

### **Three Alloy Groups for Aerospace Applications**

- 2xxx-T8xx (T6xx)
- 7xxx-T7xx (T6xx)
- 2xxx-T3xx

Each of these groups of alloys has unique benefits and shortcomings.

For predominantly damage tolerant applications, 2xxx-T3xx products are commonly used, despite numerous shortcomings as follows:





#### **Damage Tolerance Capability of 2xxx alloys**

#### <u>Limitations of –T3xx type temper</u>

- a. Limited Product Thickness
  - poor SCC resistance for thick plate (Slow Quench)
- b. Limited Product Forms
  - Very large amount of cold work by "cold rolling" is available <u>only</u> for thin plate
- c. Limited Fabrication Process
  - Age Forming cannot be utilized.
  - Cannot be processed to "O-temper" product
     Formability of –O temper (annealed) is not available
- Therefore, it would be desirable to develop a 2xxx alloy in an artificially aged temper (T6 or T8 type temper) having DT capabilities of T3xx type temper product.





### II. Metallurgical benefits of Al-Cu-Mg-Ag alloy system\*

Goal: 2xxx alloy in an artificially aged temper (T6 or T8 type temper) having Damage Tolerance (DT) and Durability (D) capabilities of T3xx type temper product.

element	Si	Fe	Cu	Mn	Mg	Ag
wt.%	0.1	0.15	4.5 - 5.5	0.20 - 0.6	0.20 - 0.8	0.15 - 0.6

#### Metallurgical Attributes of Alloy 2139

Major strengthening phase is  $\Omega(Al2Cu)$  phase

- $\Omega$  phase nucleates homogeneously in the grain matrix without cold work
- This leads to less GB precipitation and reduces propensity for intergranular fracture

Contains no Zr as a dispersoid forming element

- Reduces GB precipitation

Contains Mn as a dispersoid forming element

- Reduces Planar slip to improve Toughness



note:This part has been published in the proceedings of The 10<sup>th</sup> International Conference of Aluminum Alloys at Vancouver, Canada, June 2006



# Addition of small amounts of Mg and Ag to Al-Cu alloys promotes the nucleation of plate-like precipitates known as $\Omega$ (Al<sub>2</sub>Cu) phase.

alloy	example	strengthening	nucleation	
system	<u>alloys</u>	<u>phase</u>	mode	cold work?
Al-Cu-Mg Al-Cu-Mg-Ag	2219,2519 2024 ,2014 <b>2139</b>	θ' (Al <sub>2</sub> Cu) S' (Al <sub>2</sub> CuMg) Ω (Al <sub>2</sub> Cu)	heterogeneous heterogeneous homogeneous	yes yes no
Al-Zn-Mg	7039,7108	η', η (MgZn2)	homogeneous	no
Al-Zn-Mg-Cu	7050,7075	η', η (MgZn₂)	homogeneous	no

#### Homogeneous nucleation mechanism of $\Omega$ phase

- achieve high strength without high level of cold work prior to artificial age.
- more uniform distribution of precipitates without relying on dislocations, sub-grain and grain boundaries as nucleation sites.
- less prone to intergranular and intersubgranular fracture after artificial age





### III. Effect of dispersoid forming elements in 2139 –T8\*\*

#### Optimization of Dispersoid Forming Element – Why Mn?

The experiments were conducted with industrial scale trials using full plant size ingots (13,000 lbs. ingots)

#### **Comparison I**

Dispersoid forming Elements; Mn vs. Zr

	Cu	Mg	Ag	Mn	Zr
Alloy A (Mn)	4.90	0.46	0.38	0.32	0.002
Alloy B (Zr)	4.81	0.45	0.39	0.01	0.14

#### **Comparison II**

Dispersoid forming Elements; Mn vs. Mn + Zr

	Cu	Mg	Ag	Mn	Zr
Alloy S (Mn)	4.95	0.45	0.34	0.26	0.001
Alloy P (Mn+Zr)	4.93	0.43	0.34	0.20	0.09



note: This part has been published in the proceedings of The 10<sup>th</sup> International Conference of Aluminum Alloys at Vancouver, Canada, June 2006




#### Alloy A with Mn shows higher combination of Strength and Fracture Toughness

### Effect of Dispersoid; Mn vs. Zr

1 inch ga 2139-T8 plate CT specimen B=1 in. W=3 in.

#### Effect of Dispersoid; Mn vs. Zr

1 inch ga 2139-T8 plate, M(T) specimen B=0.25 in. W=16 in.








<u>Difference in Fracture Toughness between alloy A(w/Mn) and alloy B(w/Zr) becomes more pronounced at -65 deg F which is the service environment for aircraft flying at high altitude</u>

### Fracture Toughness of 0.28 inch plate








### SEM Fractography after fracture tests at -65 deg F

ALLOY A: Al-Cu-Mg-Ag-Mn alloy



**ALLOY B: Al-Cu-Mg-Ag-Zr alloy** 




Figure 1. Fractography of A sample tested at -65°F (showing ductile fracture mode)




Figure 2. Fractography of B sample tested at -65°F (showing many areas with brittle fracture mode)



#### Alloy A(w/Mn) shows better ballistic performance, compared to Alloy B(w/Zr)

#### **Effect of Dispersoid on Ballistic Performance**

1 inch ga 2139-T8 plate are tested per MIL-DTL-46192C



Note: FSP; Fragmented Shrapnel Penetration tests AP; Armor Piercing tests




#### Effect of Dispersoid; Mn vs. Mn+Zr

0.125 in ga. 2139-T851 Sheet W=30 in. M(T) specimen

## Adding Zr to Al-Cu-Mg-Ag-Mn alloy lowers Fracture Toughness


- This indicates that Zr containing dispersoids could be detrimental to Damage Tolerance of Al-Cu-Mg-Ag alloy in T8 temper








### Large particles of Mn containing dispersoids in Al-Cu-Mg-Ag-Mn alloy



Al-Cu-Mg-Ag-Mn alloy



Al-Cu-Mg-Ag-Zr alloy

Note: Both figures are under identical magnification.





# Zr-containing particles at (sub)grain boundaries provide nucleation sites for Cu-containing particles




Fig. a) BF image of  $\theta$ ' phase(Al<sub>2</sub>Cu) formed at Al<sub>3</sub>Zr

Fig. b) DF image shows  $\theta$ ' in the matrix and Al<sub>3</sub>Zr by using  $\theta$ ' reflection

Note: Fig. a and Fig.b are under identical magnification.





## Zr-containing particles at (sub)grain boundaries provide nucleation sites for Cu-containing particles.

- This would weaken grain boundaries by further promoting boundary precipitation and PFZ's.


Alloys with weak g.b. strengths are more prone to intergranular fracture at very low service temperatures or at extremely high deformation rates typical of ballistic impact.






#### Schematic Diagram of Deformation Mode for G.B. Failures

Homogeneous deformation requires both cross slip and planar slip mechanisms



#### **Cross slip mechanism**

- -Thermally activated process
- -Relying on diffusion kinetics



#### At Low Temp. or At Very High Deformation rate

- Cross Slip mechanism is less favored
- Planar Slip mode becomes dominant





## Damage Tolerance Capability of 2139 plate can be evaluated by comparing to the commonly used Damage Tolerant Al alloys in Aerospace and Military Applications

### 2324-T39; Lower wing plate for large commercial Airplanes (1-1.5")

- best fatigue resistant Al alloy

#### 2124-T8151; Ribs & Spars for Fighter plane (1"- 6")

- best fracture toughness in 2xxx-T8xx product

#### 7475-T7351; Lower Wing for Small Airplanes (1.5" - 4")

- best fracture toughness in 7xxx-T7xx product

#### 7050-T7451; Ribs & Spars for all aircraft (1.5" - 8"(10"))

 most commonly used alloy for thick gauge application for good combined properties


#### **2519-T87**; Armor plate application (1" – 6")

- best ballistic performance






#### Property Summary of 1" ga. 2139-T8 Plate



M(T) B=0.25 in.(6.3mm) W=16 in.(406mm)



#### **Corrosion Resistance**

- ■2139-T8; 1.0 inch ga. plate
- → SCC: Passed at 30, 35 & 40 ksi for 20 days when tested in ST per ASTM G47 by ASTM G-38
- → EXCO = EA @ T/2, EB @ T/10, when tested per ASTM G34



#### Property Summary of 1" ga. 2139-T8 Plate

### Double Open Hole Axial Fatigue Tests on 1.0 in. ga. 2139-T8 Plate

L -dir. at T/2 Max. Stress; 20 ksi, R-Ratio; 0.1 Freq.; 15 Hz

2139-T8					
S.N.	Cycle to Fail	Fail. Loc.			
1	1,500,000	Discont.			
2	1,500,000	Discont.			
3	1,500,000	Discont.			
4	842,407	A-Hole			
5	873,461	A-Hole			

Avg.	1,199,521
AVE.	1,1//,5/41

2324-T39; (Lot 1)					
S.N.	Cycle to Fail	Fail. Loc.			
1	599,342	A-Hole			
2	260,582	B-Hole			
3	249,950	A-Hole			
4	229,226	B-Hole			
5	243,678	B-Hole			

Avg.	293,569

2324-T39; (Lot 2)					
S.N.	Cycle to Fail	Fail. Loc.			
1	953,753	B-Hole			
2	224,820	A-Hole			
3	266,575	A-Hole			
4	177,150	A-Hole			
5	292,459	B-Hole			

Avg. 312,104








#### Ballistic Performance of 1.0 in. ga. 2139-T8 plate

1 inch ga 2139-T8 & 2519-T87 plates are tested per MIL-DTL-46192C



Note: FSP; Fragmented Shrapnel Penetration tests AP; Armor Piercing tests





#### **Property Summary of 1" ga. 2139-T8 Plate**

- 1. Fracture toughness of 2139-T8 plate exceeded that of 2324-T39 and 7475-T7351 plate
- 2. Fatigue Resistance of 2139-T8 plate exceeded that of 2324-T39 plate
- 3. Ballistic performance of 2139-T8 plate exceeded that of 2519-T87 plate
- 4. 2139-T8 plate showed good SCC resistance and EXCO test results





### IV. Development of 2139 thick gauge plate product

To evaluate the Damage Tolerance capability of thick gauge plate product, three gauges of 2139-T8 plate were produced from the two plant size ingots (13,000 lbs. ingots)

- → 2.0 inch (51 mm)
- → 4.25 inch (108 mm)
- → 6.125 inch (156 mm)

#### Chemistry of two 2139 alloy ingots


	Cu	Mg	Mn	Ag	Zr
min	4.5	0.2	0.2	0.15	0
max	5.5	0.8	0.6	0.6	0.03





#### **Damage Tolerance of 2139-T8 Thick Plate**

### Effect of Plate Gauge on TYS in L-dir. of 2139-T8





### Mechanical Properties of 2 inch gauge 2139-T8 plate

Age	Test dir.	UTS(ksi)	TYS(ksi)	Elong.(%)	K1c(ksiVin.)
Age	L	68.9	65.7	15.0	57.8
condition	LT	71.9	65.1	9.0	46.5
1	ST	69.3	62.0	9.5	34.4*
Age	L	68.9	65.5	14.0	58.2*
condition	LT	71.2	64.3	9.0	44.5
2	ST	70.4	63.4	11.0	40.3*

L-T, T-L; tested at t/4 location with B=2", W=4"

S-L; tested at t/2 with B=0.75", W=1.5"


\*; invalid per Invalidity criteria #1 in ASTM E399-05





## Damage Tolerance of 2139-T8 Thick Plate 2 inch (51 mm) plate

## Plane Strain Fracture Toughness of 2 inch ga. Plate 2139-T8, 7475-T7351 & 2124-T8151








## Damage Tolerance of 2139-T8 Thick Plate 2 inch (51 mm) plate

#### **Fatigue Crack Growth Rate in L-T**

Temperature: +75 R-Ratio: 0.1 Lab Air, 10 Hz







#### Mechanical Properties of 4.25 inch gauge 2139-T8 plate

Age	Test dir.	UTS(ksi)	TYS(ksi)	Elong.(%)	K1c(ksiVin.)
Age	L	71.5	66.8	13.0	44.4
condition	LT	72.8	65.9	9.5	36.8
1	ST	67.9	59.7	6.4	34.6
Age	L	72.2	67.1	13.0	48.1
condition	LT	73.0	66.4	9.0	35.6
2	ST	68.1	61.4	5.0	33.8
Age	L	72.4	67.3	11.5	45.2
condition	LT	73.5	66.6	8.0	36.3
3	ST	68.7	61.2	5.7	34.2

L-T, T-L; tested at t/4 location with B=2", W=4"


S-L; tested at t/2 with B=0.75", W=1.5"






## Damage Tolerance of 2139-T8 Thick Plate 4.25 inch (108 mm) plate

## Fracture Toughness of 4.25" in L-T 2139-T8, 2124-T8151 & 7050-T745



## Fracture Toughness of 4.25" in T-L 2139-T8, 7050-T7451 & 2124-T8151









## Damage Tolerance of 2139-T8 Thick Plate 4.25 inch (108 mm) plate

## Fracture Toughness of 4.25" in S-L 2139-T8, 7050-T7451 & 2124-T8151



#### Comparison of FCGR in L-T

Temp:+75 R-Ratio: 0.1 Lab Air Freq: 10







#### Mechanical Properties of 6.125 inch gauge 2139-T8 plate

Age	Test dir.	UTS(ksi)	TYS(ksi)	Elong.(%)	K1c(ksiVin.)
Age	L	73.1	68.1	12.0	33.0
condition	LT	73.7	66.0	9.5	32.2
1	ST	67.2	59.3	4.7	36.5
Age	L	72.9	67.4	10.0	32.9
condition	LT	73.4	65.5	9.5	32.2
2	ST	67.8	60.2	4.7	33.9
Age	L	72.7	67.5	9.5	32.3
condition	LT	73.6	66.2	8.0	31.9
3	ST	68.1	59.8	6.1	33.5


L-T, T-L; tested at t/4 location with B=2", W=4"

S-L; tested at t/2 with B=0.75", W=1.5"






### Damage Tolerance of 2139-T8 Thick Plate 6.125 inch (156 mm) plate





## **Damage Tolerance of 2139-T8 Thick Plate**

## 6.125 inch (156 mm) plate







## Texture components (volume %) of 2139-T3 plate at two through-thickness locations from four different gauge plates

#### Volume% of Texture components of 2139 -T3 plate at t/2 location

Alloy	Gauge(inch)	Temper	Location	Cube	Goss	Brass	S	Cu	R-Cube	Cube+Goss	Brass+S
2139	1	Т3	t/2	10.7	2.0	5.0	7.8	3.6	2.3	12.6	12.8
2139	2	Т3	t/2	3.0	2.1	3.7	5.4	2.4	6.8	5.0	9.0
2139	4.25	Т3	t/2	5.0	2.1	2.6	4.1	2.4	8.1	7.1	6.7
2139	6.125	Т3	t/2	4.5	2.7	4.6	6.0	3.5	3.5	7.1	10.6

#### Volume% of Texture components of 2139 -T3 plate at t/4 location


Alloy	Gauge(inch)	Temper	Location	Cube	Goss	Brass	S	Cu	R-Cube	Cube+Goss	Brass+S
2139	1	Т3	t/4	6.2	1.6	5.3	9.2	4.9	4.1	7.9	14.4
2139	2	Т3	t/4	3.4	3.4	5.6	8.0	2.3	6.1	6.7	13.6
2139	4.25	Т3	t/4	4.4	1.9	8.4	11.7	4.1	2.9	6.3	20.1
2139	6.125	Т3	t/4	2.8	2.7	7.6	10.6	5.0	3.6	5.4	18.2

Note:

 $Cube: \{100\} < 100 > Goss; \{011\} < 100 > S; \{123\} < 634 > Brass; \{011\} < 211 > Cu; \{112\} < 111 > Rotated Cube; \{100\} < 011 > Cube; \{100\} < 011 >$ 




### Texture components (vol%) of 2139-T3 plate at t/4





## Recrystallization(Cube&Goss) and Deformation (S & Brass) components of 2139-T3 plate at t/4







#### SCC tests of 2139-T8 plate in ST direction per ASTM G47 by ASTM G-38

## SCC tests in ST direction for 20 days per ASTM G47 by ASTM G-38

<u>Test</u>	<u>Plate</u>	<u>Age</u>	Test	<u>Test</u>	<u>Applied</u>	
<u>Speciemen</u>	<u>Ga.(in).</u>	(hours)	<u>Plane</u>	Orient.	<u>Stress(ksi)</u>	Pass /Fail
1	2	24	t/2	ST	30	Pass
2	2	24	t/2	ST	30	Pass
3	2	24	t/2	ST	30	Pass
1	4.25	24	t/2	ST	30	Pass
2	4.25	24	t/2	ST	30	Pass
3	4.25	24	t/2	ST	30	Pass
1	6.125	20	t/2	ST	30	Pass
2	6.125	20	t/2	ST	30	Pass
3	6.125	20	t/2	ST	30	Pass





### V. Summary & Conclusion

- 1. 2139-T8 thick plate was evaluated in three gauges, 2.0"(51mm), 4.25"(108mm) and 6.125"(156mm)
- 2. 2139-T8 plate did not show loss in strength as gauge increases as seen in other 2xxx-T8xx plate products. Instead, 2139-T8 plate maintained strength levels comparable to 7050-T7451 in all gauges tested
- Combined properties of strength and fracture toughness in three testing directions exceeded those of other conventional damage tolerant Al alloys in all three gauges
- 4. 2139-T8 plate showed exceptionally good FCG Resistance in all three gauges
- 5. Over all, 2139-T8 thick plate demonstrated superior DT capability, compared to 2324-T39, 7475-T7351, 2124-T8151, and 7050-T7451 in comparable gauges tested so far up to 6 inches thick (156mm)



#### REPORT DOCUMENTATION PAGE

Form Approved OMB No. 0704-0188

The public reporting burden for this collection of information is estimated to average 1 hour per response, including the time for reviewing instructions, searching existing data sources, gathering and maintaining the data needed, and completing and reviewing the collection of information. Send comments regarding this burden estimate or any other aspect of this collection of information, including suggestions for reducing this burden, to Department of Defense, Washington Headquarters Services, Directorate for Information Operations and Reports (0704-0188), 1215 Jefferson Davis Highway, Suite 1204, Arlington, VA 22202-4302. Respondents should be aware that notwithstanding any other provision of law, no person shall be subject to any penalty for failing to comply with a collection of information if it does not display a currently valid OMB control number.

PLEASE DO NOT RETURN YOUR FORM TO THE ABOVE ADDRESS.

1. REPORT DATE (DD-MM-YYYY)	2. REPORT TYPE		3. DATES COVERED (From - To)			
01-12 - 2007	Contractor Report		10-1-2005 to 12-31-2006			
4. TITLE AND SUBTITLE		5a. CONTRACT NUMBER				
	rovement of Aerospace Aluminum	NNL(	04AB64T			
Alloys - Development of AL-Cu-	Mg-Ag Alloy (2139)	5b. GRANT NUMBER				
		5c. PR	ROGRAM ELEMENT NUMBER			
6. AUTHOR(S)		5d. PF	ROJECT NUMBER			
Cho, Alex; Lisagor, W. Barry; and	d Bales, Thomas T.					
		5e. TA	SK NUMBER			
		5f. WC	ORK UNIT NUMBER			
		23-79	4-40-4L			
7. PERFORMING ORGANIZATION I	NAME(S) AND ADDRESS(ES)		8. PERFORMING ORGANIZATION REPORT NUMBER			
NASA Langley Research Center			KEI OKI NOMBEK			
Hampton, VA 23681-2199						
9. SPONSORING/MONITORING AG	ENCY NAME(S) AND ADDRESS(ES)		10. SPONSOR/MONITOR'S ACRONYM(S)			
National Aeronautics and Space A Washington, DC 20546-0001	Administration		NASA			
<b>3</b> ,			11. SPONSOR/MONITOR'S REPORT NUMBER(S)			
			NASA/CR-2007-215094			
12 DISTRIBUTION/AVAILABILITY S	TATEMENT					

Unclassified - Unlimited Subject Category 26

Availability: NASA CASI (301) 621-0390

#### 13. SUPPLEMENTARY NOTES

Cho: Alcan Rolled Products, Ravenswood, WV; Lisagor and Bales: Analytical Services & Materials, Inc., Hampton, VA. Langley Technical Representative of the Contracting Officer: John A. Wagner An electronic version can be found at http://ntrs.nasa.gov

#### 14. ABSTRACT

This final report supplement in presentation format describes a comprehensive multi-tasked contract study to continue the development of the silver bearing alloy now registered as aluminum alloy 2139 by the Aluminum Association. Two commercial scale ingots were processed into nominal plate gauges of two, four and six inches, and were extensively characterized in terms of metallurgical and crystallographic structure, and resulting mechanical properties. This report includes comparisons of the property combinations for this alloy and 2XXX and 7XXX alloys more widely used in high performance applications. Alloy 2139 shows dramatic improvement in all combinations of properties, moreover, the properties of this alloy are retained in all gauge thicknesses, contrary to typical reductions observed in thicker gauges of the other alloys in the comparison. The advancements achieved in this study are expected to result in rapid, widespread use of this alloy in a broad range of ground based, aircraft, and spacecraft applications.

Al-Cu-Mg-AG alloy; Mechanical properties; Fracture toughness; Fatigue crack growth; Texture

16. SECURITY CLASSIFICATION OF:			17. LIMITATION OF ABSTRACT	18. NUMBER OF	19a. NAME OF RESPONSIBLE PERSON
a. REPORT	b. ABSTRACT	c. THIS PAGE		PAGES	STI Help Desk (email: help@sti.nasa.gov)
					19b. TELEPHONE NUMBER (Include area code)
U	U	U	UU	44	(301) 621-0390